


Parts List for HB30 Head Boat Reel



HB30 Head Boat Reel- Parts List

Part No.	Part Name
1	Right Side Plate
2	Right Outer Ring
3	Right Inner Ring
4	Gear Sleeve
5	Bridge-Main Shaft Assembly
6	Gear Sleeve Pin
7	Fiber Washer
8	Main Gear with Bushing
9	Metal Drag Washer (2 required)
10	Drag Tension Washer (3 required)
11	Squared Drag Washer
12	Spring Washer
13	Drag Spacing Sleeve
14	Star Drag
15	Essentric Jack
16	Pinion Gear
17	Pinion Yoke
18	Pinion Yoke Spring (2 required)
19	Dog
20	Dog Spring
21	Upper Bridge Screw (2 required)
22	Lower Bridge Screw (2 required)
23	Essentric
24	Essentric Spring
25	Essentric Lever
26	Retainer Washer
27	Essentric Lever Screw
28	Handle Screw
29	Handle Lock Screw
30	Handle
31	Right Tension Control Cap
32	Left Side Plate
33	Left Outer Ring
34	Left Inner Ring
35	Spool Assembly
36	Clicker Switch
37	Clicker Switch Washer
38	Clicker Tongue
39	Clicker E-Ring
40	Stand Screw (4 required)
41	Post Screw (6 required)
42	Left Tension Control Cap
43	Conversion Post
44	Clicker Spring
45	Clicker Spring Screw
46	Conversion Post Cap
47	Frame Post (3 required)
48	Clamp Screw (2 required)
49	Stand
50	Clamp Screw Nut (2 required)
51	Rod Clamp
52	Clamp Screw Set (2 required)
53	Conversion Post Cap Spring
54	Left Tension Control Spring
55	Complete Bridge Assembly (parts 4,5 &6)